

ARGUS[™]

Power System Manual CXPS 24-48-i, 8kW DC-DC Converter System

053-996-B0



Visit us at www.argus.ca

Power

This page intentionally left blank.

Power System Manual

CXPS 24->48-i, 8kW DC-DC Converter System

053-996-B0

Drawing List:

The following drawings are included in this manual to provide the necessary information required for routine operation and fault diagnosis of the system.

System Specifications	053-996-B1
CXCI Specifications	707-492-B1
Safety and Installation Instructions	053-996-C0
Outline Drawing	053-996-06
Schematic, Power System	053-996-05
Customer Connections	053-996-08
Warranty and Service	048-700-10
Service Centers	048-693-10

Manuals to be included with this package are as follows:

Cordex Controller Software (Current Version)	CXC SOFT
--	----------

Specifications for Argus' CXPS 24-48-i 8kW DC-DC Converter System

Output

Voltage:		-48 to -54Vdc
Current:	System:	148A maximum @ 54Vdc
	Converter Module:	37A maximum @ 54Vdc
Power:	System:	8000W maximum @ 54Vdc output
	Converter Module:	2000W maximum @ 54Vdc output
Heat Dissipation (per converter):<930 BTU per hour per converter module		
Static Regulation:		±0.1% line; -1.0% ±0.1% load
Dynamic Regulation:		<1% deviation for 50% - 100% load step; settling to 0.1% in <2ms
Electrical Noise:		<38dBrnC (voice band) <10mVrms 10kHz to 10MHz (wideband) <150mVp-p 10kHz to 100MHz <1.0mV (psophometric)
Acoustic Noise:		<60dBa @ 1m (3ft.) @ 30°C (86°F)

Input

Voltage:		+21 to +30Vdc
Efficiency:		>88% @ 50 to 100% load
Electrical Noise:		<32dBrnC (voice band) <10mVrms 10kHz to 10MHz (wideband) <150mVp-p 10kHz to 100MHz
Current:	System:	<376A @ +24V input (432A maximum)
	Converter:	<94A @ +24V input (108A maximum)

Environmental

Temperature:	-40 to +65°C (-40 to +149°F) standard operating -40 to +70°C (-40 to +158°F) storage
Humidity:	0 to 95% non-condensing
Elevation:	-500 to +2800 m (-1640 to 9186 ft)

Miscellaneous

Number of Converters:	Up to four (4) Cordex CXDF 24-48/2kW modules; Argus #012-526-20
Distribution Capacity, Load:	18x 1-pole positions, plug-in type (bullet terminals), AM-style, 1 to 100A NOTE: Multiple pole breakers, 125 to 250A, also available
Dimensions:	438mm W x 222mm H x 310mm D (17.24" W x 8.75" H x 12.2" D) [-000 configuration – excludes mounting brackets, rear cover, and module handles. For additional options see outline drawings at the rear of this manual.]

Connections

Load Connections:	AM breakers (1-pole): 1/4" holes on 5/8" centers AM breakers (multiple pole): 3/8" holes on 1" centers (with adapter)
Battery Terminations:	AM breakers (1-pole): 1/4" holes on 5/8" centers AM breakers (multiple pole): 3/8" holes on 1" centers (with adapter)
Alarm/Signal Connections:	0.081mm ² to 0.55mm ² (#28 to #20 AWG)
DC Hot Input:	3/8" holes on 1" centers (1 set)
DC Gnd Input:	3/8" holes on 1" centers (1 set)

NOTE: *Back-to-back lug installation is possible. See -08 drawing at rear of manual.*

Cable Access:	Front and top
---------------	---------------

Recommended Disconnect Device and Wire Sizing

Input Wire Size (minimum):

For Input LVD* of 22Vdc or Higher

* set via Cordex controller

500A breaker

2x 250MCM ≥ 90°C rated @ 60°C

For Input LVD* 21 to 22Vdc

* set via Cordex controller

600A breaker

2x 350MCM ≥ 90°C rated @ 60°C

Output Wire Size (minimum): 3/0AWG ≥ 90°C rated

Safety

NOTE: *Safety certifications performed at converter level only.*

EN 60950:	Converter output shall be rated SELV suitable for connection to TNV-1 circuits
UL:	60950
CSA:	C22.2 No. 60950
CE:	EN 60950, CB Scheme 73/23/EEC Low Voltage Directive with amendment 93/68/EEC
Telcordia (Bellcore):	GR-1089-CORE (requirements applicable to converter)

Other Referenced Standards

This product is designed to meet or exceed the following:

FCC 47 CFR part 15:	Class A radiated and conducted EMI
EN 55022 (CISPR 22):	Class A radiated and conducted EMI
ENV 50204:	Radiated electromagnetic immunity (digital radio and telephones)
EN 61000-4-2:	ESD Immunity
EN 61000-4-3:	Radiated Electromagnetic Immunity
EN 61000-4-4:	Electrical Fast Transients Burst Immunity
EN 61000-4-6:	Conducted Electromagnetic Immunity
CAN/CSA (NRTL/C):	C22.2 No. 60950-1-03
ANSI/UL (NTRL):	60950-1
Bellcore GR-63-CORE:	Vibration and Shock
Bellcore GR-1089-CORE:	Electromagnetic Compatibility and Electrical Safety

*The above information is valid at the time of publication. Consult factory for up-to-date ordering information.
Specifications are subject to change without notice.*

Specifications for Argus' CXCI Cordex Controller Integrated Model

Basic Unit, CXCI

Input Voltage:	17 to 65Vdc within rated limits [9 to 65Vdc for shelf systems with 12V rectifiers (List 3)]
Current:	<100mA @ 48Vdc <200mA @ 24Vdc
MTBF:	472,000 hours @ 25°C (77°F)
EMC:	The unit meets requirements of: ICES-003 Class B EN 55022 Class B (CISPR 22) EN 61000-4-2 ESD EN 61000-4-3 Radiated Immunity EN 61000-4-4 EFT /Burst EN 61000-4-6 Conducted Immunity FCC Part 15 Class B, FCC Part 68

In accordance with FCC requirements, we provide the following statement as specified in the FCC guidelines for conformance to Part 15, Class B:

NOTE: *This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications to this equipment not expressly described in this manual could void the FCC compliance.

Environmental

Temperature:	-40 to 65°C standard @ 3000m derate to 55°C @ 4000m (-40 to 149°F derate to 131°F @ 13124ft)
Humidity:	0 to 95% non-condensing
Elevation:	-500 to +4000m (-1640 to 13124 ft)

Hardware Specifications, CXCI

CPU:	Coldfire
RAM:	8MB
Flash:	4MB standard
Display:	4 digit LCD
Front Panel Controls:	Display pushbutton toggle switch for voltage (V) or current (A) CXCI reset switch (soft reset button; hold for 3 seconds to reset IP)
LED's:	System OK (Green) Power System Minor Alarm (Yellow) Power System Major Alarm / Controller Fail (Red)
Audio:	Built-in speaker for alarm and popup message tones
Dimensions:	88mm H x 26mm W x 280mm D (3.5" H x 1" W x 11" D)
Weight:	0.34 kg (0.75 lb.)
Mounting:	Integrated on Cordex 2RU series 19" and 23" shelves
Relay Outputs:	Four (4) Form C, 60Vdc 1A maximum
Digital Inputs:	Two (2), 0 to 60Vdc
Analog Inputs:	One (1) DC voltage, 0 to 60Vdc One (1) DC current, $\pm 50\text{mV}$ Two (2) temperature, 0 to 20Vdc with power source
Communication Ports:	Ethernet RJ-45, Argus Modem DB-9, CAN [see shelf specifications]

Recommended Signal Wire Sizes (as per UL/CSA)

Wire Size Range:	0.14 to 1.50mm ² (#26 to #16 AWG)
Temperature Range:	0 to 50°C (32 to 122°F)

CAUTION – TO REDUCE RISK OF FIRE, USE ONLY 0.14mm² (#26 AWG) OR LARGER WIRE.

*The above information is valid at the time of publication. Consult factory for up-to-date ordering information.
Specifications are subject to change without notice.*

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS

This section contains important instructions that should be followed during the installation and maintenance of equipment and batteries. **Please read all of the instructions before operating the equipment, and save this manual for future reference.**

A licensed electrician **MUST** perform connections to the branch circuit of service feed. Installation of the power supply and batteries must be performed by, or under the direct supervision of service personnel knowledgeable of the required electrical and battery safety precautions.

If instructions in this manual conflict with local electrical codes, those instructions shall be superseded by the local code.

The following safety symbols will be found throughout this manual, carefully read all information and abide by the instructions:



DANGEROUS VOLTAGE
This symbol indicates a dangerous voltage exists in this area of the product.



GAS HAZARD
This symbol indicates a gas hazard exists in the area of vented batteries.



NO MATCHES OR OPEN FLAMES
This symbol indicates a fire or explosive hazard exists in the area of the product.

The following levels of warning will be used with the above symbols:

DANGER: You **WILL** be **KILLED** or **SERIOUSLY INJURED** if instructions are not followed closely.

WARNING: You **CAN** be **KILLED** or **SERIOUSLY INJURED** if instructions are not followed closely.

CAUTION: You **CAN** be **INJURED** or equipment can be **DAMAGED** if instructions are not followed closely.

Mechanical Safety

Keep hands and tools clear of fans. Fans are thermostatically controlled and will turn on automatically.

Power supplies can reach extreme temperatures under load.

Use caution around sheet metal components and sharp edges.

Electrical Safety

WARNING



Hazardous voltages are present at the input of a power system. The DC output from converters, though not dangerous in voltage, has a high short-circuit current capacity that may cause severe burns and electrical arcing.

Before working with any live battery or power system, follow these precautions:

- Remove all metallic jewelry; e.g., watches, rings, metal rimmed glasses, necklaces.
- Wear safety glasses with side shields (and prescription lenses if necessary) at all times during installation.
- Use OSHA approved insulated hand tools.

Lethal voltages are present within a power system. Never assume that an electrical connection or conductor is not energized. Check the circuit with a voltmeter with respect to the grounded portion of the enclosure (both AC and DC) prior to any installation or removal procedure.

Do not work alone under hazardous conditions.

A licensed electrician is required to install permanently wired equipment. Input voltages can range up to 240Vac. Ensure that utility power is disabled before beginning installation or removal.

Ensure no liquids or wet clothes contact internal components.

Hazardous electrically live parts inside this unit are energized from batteries even when the AC input power is disconnected.



WARNING

High leakage current – Earth connection essential before connecting supply.

Battery Safety

Servicing and connection of batteries shall be performed by, or under the direct supervision of, personnel knowledgeable of batteries and the required safety precautions.

Always wear eye protection, rubber gloves, and a protective vest when working near batteries. Remove all metallic objects from hands and neck.

Use OSHA approved insulated hand tools. Do not rest tools on top of batteries.

Batteries contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Battery post terminals and related accessories contain lead and lead compounds; wash hands after handling (California Proposition 65).



WARNING

Follow battery manufacturer's safety recommendations when working around battery systems.



WARNING

Do not smoke or present an open flame when batteries (especially vented batteries) are on charge. Batteries vent hydrogen gas when on charge, which creates an explosion hazard.

Batteries are hazardous to the environment and should be disposed of safely at a recycling facility. Consult the battery manufacturer for recommended local authorized recyclers.

TABLE OF CONTENTS

1	INTRODUCTION	1
1.1	Scope of the Manual	1
1.2	Product Overview	1
1.3	System Configurations	2
1.4	Accessories	2
2	FEATURES	3
2.1	System Overview	3
2.2	Distribution Center	3
2.3	Cordex Integrated System Controller (CXCI)	5
2.4	Cordex 24-48/2kW Converter	7
3	INSPECTION.....	9
3.1	Packing Materials.....	9
3.2	Check for Damage	9
3.3	General Receipt of Shipment.....	9
4	INSTALLATION	10
4.1	Safety Precautions	10
4.2	Tools Required.....	10
4.3	Power System Assembly and Mounting	11
4.4	Converter Module Insertion/Removal	11
4.5	Breaker Installation	11
4.6	Breaker Removal	11
5	WIRING	12
5.1	Grounding	12
5.2	Calculating Wire Size Requirements	12
5.3	Input/Output Connections	13
5.4	Alarm Connections.....	14
5.5	CAN Serial Ports	15
5.6	Network Connection and Remote Communications via CXCI.....	15
5.7	Signal Wiring Connections for CXCI.....	16
6	SYSTEM STARTUP	18
6.1	Check System Connections.....	18
6.2	Verify Input and Power the Converter Shelf	18
6.3	Converter Operation and Programming via the CXCI	18
6.4	CXCI Reset	19
7	MAINTENANCE	20
7.1	Fan Replacement.....	20
7.2	CXCI Replacement (as used with CXDF shelf)	20
8	ARGUS CONVENTIONS.....	22
8.1	Numbering System.....	22
8.2	Acronyms and Definitions	22

FIGURES

Figure 1–Front view of the 053-996-20-000 rail mount CXPS 24-48-i 8kW DC-DC Converter System 1

Figure 2–DCP03 configured for 18 load breakers..... 3

Figure 3–Internal alarm card 3

Figure 4–Internal alarm card and CXCI I/O terminal block..... 4

Figure 5–4R/8D ADIO option..... 4

Figure 6–Cortex CXCI model system controller front panel..... 5

Figure 7–CXDF 24-48/2kW modular switched mode converter..... 7

Figure 8–Example of an insulated tool kit..... 10

Figure 9–Rear view of CXPS 24-48-i 13

Figure 10–Load, and return connection locations 14

Figure 11–DCP03 wire routing example..... 15

Figure 12–Showing relay connections..... 16

Figure 13–Showing digital input connection method..... 17

Figure 14–Showing CXCI module removal (replacement) 21

1 Introduction

1.1 Scope of the Manual

This instruction manual covers the features and installation of Argus Technologies' CXPS 24-48-i 8kW DC-DC Converter System.

NOTE: *To aid the user with installation, frequent reference is made to drawings located at the rear of this manual.*

1.2 Product Overview

The CXPS 24-48-i is a complete integrated 24Vdc to 48Vdc converter system utilizing the advanced Cordex CXCI controller and 24-48V 2kW converter modules. The DCP03 300A distribution center provides front access for DC distribution and site controller connections. The system provides a maximum capacity of 8kW (148A @ 54Vdc).

The CXDF 24-48/2kW isolated DC-DC converter employs a high frequency switched mode conversion technique to provide a fully regulated and isolated -48 Volt DC output from a +24 Volt DC input.

The system can accommodate up to four CXDF 24-48/2kW DC-DC converter modules.

Converter power modules are "hot swappable" meaning they can be inserted or removed from the shelf without cutting power to or from the system or the load.

NOTE: *Converter modules are not included with the base system, but may be purchased along with the system at the time of ordering or added after the shelf has been installed.*

The shelf converter system is designed to operate with the Argus Cordex System Controller (CXC).

Controller software version 1.97 is the minimum requirement.

This system uses the CXCI integrated version of the controller, which is factory installed on the Cordex converter system shelf.

The CXC allows the user to configure, monitor and control the entire DC power system locally or remotely via (web browser) Internet Explorer® 7 or greater. Features of the unit include temperature compensation, auto equalization, remote access, e-mail alarm notification, battery diagnostics, as well as web server and SNMP support for configuration and monitoring.

Details of controller operation are provided in the current version software manual.



Figure 1–Front view of the 053-996-20-000 rail mount CXPS 24-48-i 8kW DC-DC Converter System

1.3 System Configurations

The system is available to order in the following configurations:

Description	Part Number
CXPS 24-48-i, Cordex base 24V-48V 8kW converter system, 19/23" rail mount.....	053-996-20-000

1.4 Accessories

This product is available to order with the following accessories:

Description	Part Number
Cordex DC/DC 2kW converter, 24V In – 48V Out	012-526-20
Breaker, AM-type mid-trip plug-in, 1A.....	470-300-10
Breaker, AM-type mid-trip plug-in, 3A.....	470-301-10
Breaker, AM-type mid-trip plug-in, 5A.....	470-302-10
Breaker, AM-type mid-trip plug-in, 10A.....	470-303-10
Breaker, AM-type mid-trip plug-in, 15A.....	470-304-10
Breaker, AM-type mid-trip plug-in, 20A.....	470-305-10
Breaker, AM-type mid-trip plug-in, 25A.....	470-306-10
Breaker, AM-type mid-trip plug-in, 30A.....	470-307-10
Breaker, AM-type mid-trip plug-in, 35A.....	470-308-10
Breaker, AM-type mid-trip plug-in, 40A.....	470-309-10
Breaker, AM-type mid-trip plug-in, 45A.....	470-310-10
Breaker, AM-type mid-trip plug-in, 50A.....	470-311-10
Breaker, AM-type mid-trip plug-in, 60A.....	470-312-10
Breaker, AM-type mid-trip plug-in, 70A.....	470-313-10
Breaker, AM-type mid-trip plug-in, 80A.....	470-314-10
Breaker, AM-type mid-trip plug-in, 90A.....	470-315-10
Breaker, AM-type mid-trip plug-in, 100A.....	470-316-10
Load breaker kit, AM-type mid-trip plug-in, 125A (2-pole)	747-523-20
Load breaker kit, AM-type mid-trip plug-in, 150A (2-pole)	747-524-20
Load breaker kit, AM-type mid-trip plug-in, 175A (3-pole)	747-525-20
Load breaker kit, AM-type mid-trip plug-in, 200A (3-pole)	747-526-20
Load breaker kit, AM-type mid-trip plug-in, 250A (3-pole)	747-527-20
Replacement CXDF fan assembly	747-362-20
Replacement CXCI controller.....	747-502-20
Cordex DC Modem (complete with Argus cable).....	018-585-20
Cordex Smart Peripheral Kit, 4 O/P Relays, 8 Digital I/P	747-521-20

The above information is valid at the time of publication. Consult factory for up-to-date ordering information.

2 Features

2.1 System Overview

The basic system configuration is called out by Argus part number 053-996-20-000; which includes:

- 300A DCP03 distribution center
- Cordex Integrated System Controller (CXCI)
- One (1) Cordex 24-48/2kW 4-module converter shelf
- Kydex rear covers
- 19" rack mount rails (center and flush mount)
- 19" to 23" rack mount adaptors
- System integration cabling.

2.2 Distribution Center

2.2.1 Distribution Configurations

The DCP03 contains 18 total AM-type plug-in breaker positions with two-hole connection points for both load (hot) output and the ground return bus. The breaker distribution, for the CXPS 24-48-i, is configured for 18 load breaker positions.




Figure 2–DCP03 configured for 18 load breakers

2.2.2 Internal Alarm Card

The DCP03 includes a standard alarm card providing a common interface point to internal system I/O connections and LED indication of breaker trip.

The alarm card provides terminal block access to internal signals such as binary alarms for breaker trip and analog input for voltage measurement. The terminal blocks provide a single point of access to these signals for connecting to an external system controller. Refer to the customer connections (“-08”) drawing at the rear of this manual for details on terminal block assignments.

I/O customer connection points



Figure 3–Internal alarm card

2.2.3 CXCI I/O Terminal Block

A CXCI I/O terminal block kit is installed in the UDC front door for front access to controller signals and interfaces to the CXCI controller on the converter shelf via a 25-pin D-sub wire harness.

The internal signals from the distribution center are wired to the CXCI I/O board direct from the internal alarm board. The remaining relay outputs, digital inputs, and analog inputs are available on the board via terminal blocks for customer connection of external signals. Refer to the customer connections (“–08”) drawing at the rear of this manual for details on terminal block assignments.




Figure 4–Internal alarm card and CXCI I/O terminal block

2.2.4 4R/8D ADIO (Option)

The 4R/8D ADIO Cordex peripheral may also be optionally installed on the front door of the DCP03 expanding the I/O capability of an existing Cordex controller by adding an additional 4 relays outputs and 8 digital inputs.

The 4R/8D ADIO installs on the right side on the front door. The ADIO is connected to the Cordex system via CAN communications using RJ-12 offset communications cables.

All I/O connections are made via screw terminal blocks. Refer to the customer connections (“–08”) drawing at the rear of this manual for details on terminal block assignments.

NOTE: *The 4R/8D ADIO board does not come with the CXPS 24-48-i system and is purchased separately. Consult factory for options.*




Figure 5–4R/8D ADIO option

2.3 Cordex Integrated System Controller (CXCI)

The controller is mounted in the converter system shelf and brings advanced monitoring technology to the Cordex series of converters. This compact system controller is designed for seamless operation and set up of Argus power systems and is equipped with the complete range of Cordex software (**version 1.97 minimum**) features, including the following:

- Designed to communicate directly with Cordex converters
- Provides local and remote communications
- User definable alarms
- Daily logging of power system events and system statistics.

Behind the CXCI's front panel lies the main controller motherboard, which contains a microprocessor, memory, as well as numerous other electronic components.

The CXCI includes a web server providing easy set up and monitoring using an Internet connection with (web browser) Internet Explorer® 7 or greater.

NOTE: *Details of controller operation are provided in the current version software manual.*

The data logging feature allows the user to capture data from multiple inputs, for AC/DC voltages, load/battery current, cell voltages & temperatures (automatically for up to 16 user defined logs). Typical applications of the CXCI logging include power system details, thermal performance of outdoor enclosures, battery cell specifics, or mains variations captured by an AC voltage watchdog.

A built-in audio speaker sounds an intermittent tone during active alarms.

2.3.1 System Controller Front Panel

The CXCI model has a 4-digit display for monitoring system voltage (V) and current (A). A pushbutton toggle switch allows the user to alternate the display reading.




Figure 6—Cordex CXCI model system controller front panel

2.3.2 LEDs

The CXCI has three LEDs located on the front panel. These are used to display the alarm status of the power system, CXCI progress and status during startup, and file transfers.

2.3.2.1 Alarm Conditions

The CXCI illuminates the LED that corresponds to the system alarm status. The following show the corresponding alarm status for each LED color:

Green – OK, no alarms present

Yellow – Minor alarm is present (no major alarms)

Red – Major alarm is present.

Only one LED is illuminated at a time during alarm conditions.

2.3.2.2 Progress and Status Indication

The LEDs are also used in the following situations:

Base unit validation – all three LEDs are on at the same time.

File transfer – when recovering from invalid firmware application – the red LED is illuminated.

2.3.3 Reset

A reset button is located on the front panel for restarting the CXCI's microprocessor.

NOTE: *Refer also to the software manual – always select the Reset menu item before pressing the reset button.*

2.3.4 Modem Port

The Modem port (front panel DB-9 connector, Figure 6) is designed for CXCI connection to Argus Technologies' Cordex DC Modem #018-585-20 (complete with Argus cable).

CAUTION

Connect only Argus-supplied modem and cable; otherwise, equipment damage can result.

2.3.5 Ethernet Port

The Ethernet port is designed for CXCI connection to a user supplied network (TCP/IP secured by user) via a front panel RJ-45 jack (Figure 6) and a standard network cable.

Local access (e.g. laptop computer) is also possible from the Ethernet port connection using a standard network crossover cable.

2.3.6 Analog Input Channels

The CXCI has analog input channels for voltage, current, and temperature.

2.3.6.1 Voltage Inputs

Two voltage input channels, V1 and V2, provide monitoring of discharge and charge voltage. The CXCI software is pre-configured to monitor V2 for load and for battery voltage. V2 is used as the system reference for converter float voltage, low voltage disconnect (LVD), system high voltage alarm, and system low voltage alarm. V1 is available for additional measurements.

2.3.6.2 Current Inputs

The CXCI software is pre-configured to monitor I1 for load current using an external 50mV current shunt.

2.3.6.3 Temperature Inputs

Two temperature input channels, T1 and T2, provide monitoring of battery temperature and temperature compensation (temp comp) or room/ambient temperature. A voltage is supplied to these terminals to power the temperature sensors.

2.3.7 Digital Input Channels

The CXCI has digital input channels to monitor alarm/control signals from converters (**software version 1.97 minimum**), rectifiers, and many other types of equipment.

2.3.8 Alarm and Control Output Relays

The CXCI contains Form C digital alarm output relays to extend alarms and control external apparatus. Each internally generated alarm or control signal may be mapped to any one of the relays, or, several signals may be mapped to just one relay or none at all.

2.3.9 Network Connection and Remote Communications

The Cordex system can be set up, monitored and tested via Ethernet 10/100 Base-T serial data connection. The communication protocol supports a web interface. All alarming and control of Cordex converters is accomplished with a CXCI via a CAN bus.

Controller software version 1.97 is the minimum requirement.

A step-by-step connection wizard (Windows® 2000 operating system) – provided to establish remote communications with your CXCI – is available via the Argus website (www.argusdcpower.com).

2.4 Cordex 24-48/2kW Converter

The Cordex converter modules plug into the Cordex converter shelf. The modules can be installed or removed from a system without disturbing the system provided sufficient current capacity remains. This is often referred to as “Hot Swap.”

The total output current capacity of the converter system is equal to the sum of the individual current capacities of the converter modules.



Figure 7–CXDF 24-48/2kW modular switched mode converter

2.4.1 Alarms

Converter Module Fail alarms consist of a group of (major) alarm conditions that are considered “serious” or an immediate threat to service:

- Converter failure
- Output fuse failure
- Converter off
- Thermal shutdown
- Input Voltage is out of range
- Output OVP level has been exceeded.

Converter Minor alarms consist of a group of alarm conditions that are not an immediate threat to service:

- Fan fail
- Current limit.

2.4.2 Indicators

LED indicators are provided on the front panel of the converter module to display the operational status of the module (see Table A).

Indicator Color	Associated Condition
Green (I/P)	DC INPUT OK
Green (O/P)	Converter Module Power ON
Red (FAIL)	Converter Module FAIL
Red (FAIL flashing)	Converter Minor Alarm

Table A—Module indicators and conditions

2.4.3 Regulation and Paralleling

Cordex modular converters use “output slope” or “regulation offset” to accomplish load sharing. When the converters are run in parallel (as is the case when more than one converter module is installed in the shelf) it is necessary to adjust (via the CXC: **software version 1.97 minimum**) the output voltage of the individual converter modules such that the output current is shared equally between the individual modules. At that point, the modules will track each other and share the load over the output current range of the units. The output slope value is fixed at 1.0% (1V / full current range).

2.4.4 Reverse Polarity Protection

The converter design has incorporated reverse polarity protection from the connection to a battery on the input and to a power source on the output. This prevents damage to the converter circuitry if a reverse connection is made.

3 Inspection

3.1 Packing Materials

All Argus products are shipped in rugged, double walled boxes and suspended via solid inserts to minimize shock that may occur during transportation. Packaging assemblies and methods are tested to International Safe Transit Association standards. Power systems are custom packaged in heavy-duty plywood crates.

Products are also packaged with Cortex. This plastic wrap contains a corrosive-inhibitor that protects the product from corrosion for up to two years.

NOTE: *Converters and batteries are shipped on individual pallets and are packaged per manufacturer's guidelines.*

3.1.1 Returns for Service

Save the original shipping container. If the product needs to be returned for service, it should be packaged in its original shipping container. If the original container is unavailable, make sure the product is packed with at least three inches of shock-absorbing material to prevent shipping damage.

NOTE: *Argus Technologies is not responsible for damage caused by the improper packaging of returned products.*

3.2 Check for Damage

Prior to unpacking the product, note any damage to the shipping container. Unpack the product and inspect the exterior for damage. If any damage is observed contact the carrier immediately.

Continue the inspection for any internal damage. In the unlikely event of internal damage, please inform the carrier and contact Argus Technologies for advice on the impact of any damage.

3.3 General Receipt of Shipment

NOTE: *The inventory included with your shipment is dependant upon the options you have ordered.*

3.3.1 Racks

Consult the packing slip to verify that you have the correct number of racks per your order.

3.3.2 Converters (Purchased Separately)

Consult the packing slip to verify that you have the correct number of converters per your order.

3.3.3 Miscellaneous Small Parts

Review the packing slip to determine the part number of the "configuration kits" included with your system; e.g., 053-996-20-040 for CXPS 48-1.8-i system installed in 7foot Z4 23" rack with 2x battery trays.

3.3.4 Batteries (Purchased Separately)

Verify that you have the correct number of batteries (if applicable). Refer to packing list.



**Verify that you have all the necessary parts per your order for proper assembly.
Call Argus Technologies if you have any questions before you proceed: 1 (888) 462-7487**

4 Installation

This chapter is provided for qualified personnel to install and interconnect the power components within the Argus power system. Regarding battery installation, refer primarily to the manufacturer's guidelines for more specific information.

NOTE: *To aid the user with installation, frequent reference is made to drawings located at the rear of this manual.*

4.1 Safety Precautions

Refer to the Important Safety Instructions near the front of this manual.

4.2 Tools Required

Various insulated tools are essential for DC power system installation. Use this list as a guide:

- Battery lifting apparatus (as required)
- Electric drill with hammer action, 1/2" capacity
- Various crimping tools and dies, to match lugs used in installation
- Load bank of sufficient capacity to load largest converter into current limit
- Digital voltmeter equipped with test leads
- Cable cutters
- Torque wrench: 1/4" drive, 0-150 in./lb.
- Torque wrench: 3/8" drive, 0-100 ft./lb.
- Insulating canvases as required (2' x 2', 1' x 1', 3' x 3', etc.)
- Various insulated hand tools (see Figure 8) including:
 - Combination wrenches
 - Ratchet and socket set
 - Various screwdrivers
 - Electricians knife
- Battery safety spill kit (required for wet cells only) including:
 - Protective clothing
 - Face shields
 - Gloves
 - Baking soda
 - Eye wash equipment
- Cutters and wire strippers 0.08 to 6mm² (#28 to #10 AWG).



Figure 8—Example of an insulated tool kit

4.3 Power System Assembly and Mounting

The power system must be mounted in a clean and dry environment. Sufficient free space must be provided at the front and rear of the power system. This is to meet the cooling requirements of the converters utilized in the power system and to allow easy access to the power system components.

NOTE: *The DCP03 requires at least 1RU (1.75") of space above the unit for tooling access to the load breaker ground connections. Ensure that at least 1RU of space is open in the relay rack above the DCP03.*

4.3.1 Rack Mounted Systems

Attach the power system to the customer-provided relay rack using mounting screws and star washers to ensure an electrical bond between system chassis and relay rack.

The system may be mounted into a 19" rack in either a flush or center mount position. 23" rack mounting (flush or center) is accomplished via the included 19" to 23" rack adaptors.

4.3.2 Floor Mounted Systems

Secure the system to a concrete floor utilizing either heavy duty anchors (1/2" x 2-1/2") or, for wooden floors, heavy-duty lag screws (5/8" x 2-1/2"). Use appropriately sized flat washers.

Use isolating kits if required to isolate system from the floor.

It is recommended that the relay rack be secured to the overhead cable tray. Argus does not supply the mechanical details necessary for overhead support.

4.4 Converter Module Insertion/Removal

Insert by placing the converter module on the shelf bottom and sliding the module into the rear connector (inside of the shelf). Apply pressure on the module handle to engage the rear connector in the shelf receptacle.

NOTE: *It is recommended that the first module be inserted into the front leftmost position using the side of the shelf (or the optional shelf-mounted controller) as a guide. Subsequent modules may be inserted using the previous module as a guide.*

Tighten the thumbscrew (1/4-turn) latch on the bottom of the faceplate to secure the module to the shelf.

NOTE: *Do not force a module into position if it does not seat properly. All modules are keyed to ensure that the correct module (voltage/polarity) type is used.*

To remove a module, loosen the thumbscrew (1/4-turn) latch on the bottom of the faceplate. Grasp handle and pull out, sliding the module away from the rear connector and out of the shelf.

4.5 Breaker Installation

1. Ensure mid-trip breakers are used for load and series-trip breakers are used for battery connections.
2. Turn breaker off.
3. Ensure that the breaker is right side up.
4. Align the breaker terminals with the correct holes.
5. Carefully push the breaker into position.

4.6 Breaker Removal

1. Turn breaker off.
2. Carefully pull the breaker out of position.

5 Wiring

This chapter provides cabling details and notes on cable sizing for DC applications with respect to the product.



WARNING

Ensure that power is removed by turning off converters and removing battery line fuse (if applicable) or connection before attempting work on the wiring connections. Use a voltmeter to verify the absence of voltage. Clearly mark the correct polarity of the leads before commencing work on DC connections.

Refer to the previous (Installation) chapter for safety precautions and tools required.

5.1 Grounding

The isolated power system battery return bus (BRB) should be connected to the building master ground bus (MGB) or floor ground bus (FGB) in a larger building. This acts as a system reference and as a low impedance path to ground for surges, transients, noise, etc. The MGB or FGB should have a direct low impedance path to the building grounding system. The cable from the power system to the MGB or FGB should be sized to provide sufficient ampacity to clear the largest fuse or breaker on the power system, excluding the battery protection fuse (if applicable) or circuit breaker. This is the minimum requirement; other factors including length of cable and special grounding requirements of the load should also be factored in. The insulated cable should be equipped with two-hole crimp type lugs and should not have any tight bends or kinks.

Power System Ampacity	Ground Reference Conductor Size
< 30A	#10
30 – 100A	#6-2
100 – 400A	0000
400 – 800A	350 MCM
> 800A	750 MCM

Table B–Typical ground reference conductor selection

The power system frame must also be connected to the MGB or FGB. This is done for personnel safety and to meet many Telco grounding requirements. Each bay should have its own frame or site ground connection. Refer also to the Customer Connections drawing at the rear of this manual.

5.1.1 Frame Ground

The DCP03 is grounded utilizing screws/bonding washers to the relay rack then to the main grounding bus using 35mm² (#2 AWG) insulated cable.

5.2 Calculating Wire Size Requirements

Wire size is calculated by first determining the appropriate maximum voltage drop requirement. Using the formula below calculate the CMA wire size requirement. Determine the size and number of conductors required to satisfy the CMA requirement.

$CMA = (A \times LF \times K) / AVD$, where:

CMA = Cross section of wire in circular MIL area

A = Ultimate drain in amps

LF = Conductor loop feet

K = 11.1 constant factor for commercial (TW type) copper wire

AVD = Allowable voltage drop

Check again that the ampacity rating of the cable meets the requirement for the installation application. Consult local electrical codes (NEC, CEC, etc.) for guidelines. If required, increase the size of the cable to meet the code.

5.3 Input/Output Connections



WARNING

Leave cables or bus bars disconnected at battery (if applicable) and verify output polarity using a voltmeter. Make battery connections only after all other wiring is completed.

DC wire shall be UL approved XHHW or RHH/RHW (for Canadian users, RW90 Type). Control and sense wires shall be UL approved Style 1015 (for Canadian users, TEW type).

Terminate cable leads with appropriate crimp lugs. Remove Kydex covers to access input/output connections.

Secure the positive and negative to the shelf post of the correct polarity; i.e., +V_{cable} to +V_{post}. Ensure the washers are on the bolts in the same order in which they were shipped from the factory.

The common output leg of the converter system should be connected to ground. This is typically done at the load common termination point.

Refer to guidelines supplied with the load equipment. Typically distribution cables are sized to provide a 0.5V loop drop at full load as well as meeting ampacity requirements of the protection fuse or circuit breaker.

5.3.1 24Vdc Input to System

The system contains bus (bar) input for hot and return connections. The CXPS 24-48-i system is configured for wiring with respect to converter shelf output integration to the distribution panel. Refer to Figure 9 below. +24Vdc input is connected to the converter shelf. The negative ground input connection is made via the distribution center.

NOTE: *Bus bar inputs are fixed for hot and return placement. A right angle adapter may be factory-installed for the +24Vdc input; if not, a kit will be supplied for customer use.*



Figure 9—Rear view of CXPS 24-48-i showing factory wiring, input (and return) to system

WARNING

Ensure the correct polarity is used for all cable terminations.

5.3.2 Distribution Cabling

Refer to guidelines supplied with the load equipment. Typically distribution cables are sized to provide a 0.5V loop drop at full load as well as meeting ampacity requirements of the protection fuse or circuit breaker.

Distribution cabling must be terminated with 1/4"–5/8"C lugs for connecting to DCP03.

5.3.3 Breaker Output (Hot) Connections

Connect breaker (hot) output connections before connecting the breaker returns. Secure two hole lugs to the 1/4" studs (on 5/8" centers) using the supplied hardware with the DCP03. Cables should run directly out the rear of the distribution center. Refer to Figure 10.

5.3.4 Breaker Return (Ground) Connections

Connect breaker (ground) output connections to the DCP03 ground bar. Secure two hole lugs to the 1/4" holes (on 5/8" centers) using the supplied hardware with the DCP03. Cables should run directly out the rear of the distribution center above the breaker (hot) output cables. Refer to Figure 10.




Figure 10–Load, and return connection locations

5.4 Alarm Connections

NOTE: To aid the user with installation, frequent reference is made to drawings located at the rear of this manual. Custom configurations may be detailed within the Argus power system documentation package.

For terminal block connections, the recommended wire sizes are 0.14 to 1.50mm² (#26 to #16 AWG) for the temperature range of 0 to 50 deg. C (as per UL/CSA).



CAUTION: to reduce risk of fire, use only 0.14mm² (#26 AWG) or larger wire.

Route via wire-ways and use existing cable clamps to secure to existing (factory) wire harness along with customer run signal wires. Ensure signal wires are routed along hinge point of front door so door opening and closing won't require excess wire slack. Refer to Figure 11 for wire routing example.

Terminal block connections for the internal alarm card or CXCI I/O should be routed along the left side of the DCP03 (looking at unit from front). Connections to the optional 4R/8D should be routed along the right hand side of the DCP03. Refer to the customer connections ("–08") drawing at the rear of this manual for details on terminal block assignments.




Figure 11–DCP03 wire routing example
(Photo is for reference only – subject to installation requirements)

5.5 CAN Serial Ports

Two CAN Serial ports (modular jacks with offset latches), for communications with Argus' Cordex converters and other CAN-enabled equipment (nodes) on the same system, are located on the side of the converter shelf. CAN ports may also be found on the optional 4R/8D ADIO Cordex peripheral (Figure 11).

Daisy-chain from node to node (CAN OUT of one shelf to CAN IN of another) as necessary and ensure that only the last shelf is terminated as follows:

5.5.1 CAN Termination

A CAN termination jumper is located beside the rightmost converter connector on the front of the shelf backplane. See the customer connections drawing for your shelf.

The CAN bus may be OPEN to the next node in the system or TERMINATED on the final node on the CAN bus.

5.6 Network Connection and Remote Communications via CXCI

The Cordex system can be set up, monitored and tested via Ethernet 10/100 Base-T serial data connection. The communication protocol supports a web interface.

NOTE: *Pinouts are shown in customer connections drawing.*

Some standard scenarios are described below:

5.6.1 Ethernet Port for Network Connection (Standard Network Cable)

The Ethernet port is designed for CXCI connection to a user supplied network (TCP/IP secured by user) via a front panel RJ-45 jack.

Connect using a standard network cable.

5.6.2 Ethernet Port for Local Connection (Crossover Cable)

Local access (e.g. laptop computer) is also possible from the Ethernet port connection.

Connect using a standard network crossover cable.

5.6.3 CXCI Modem Port (Argus Cable)

The Modem port (front panel DB-9 connector, Figure 6) is designed for CXCI connection to Argus Technologies' Cordex DC Modem #018-585-20.

Connect using the Argus-supplied cable.

CAUTION

Connect only Argus-supplied modem and cable; otherwise, equipment damage can result.

5.7 Signal Wiring Connections for CXCI

NOTE: To aid the user with installation, frequent reference is made to drawings located at the rear of this manual. Custom configurations may be detailed within the Argus power system documentation package.

For terminal block connections, the recommended wire sizes are 0.14 to 0.75mm² (#26 to #18 AWG) for the temperature range of 0 to 50 deg. C (as per UL/CSA).



CAUTION: to reduce risk of fire, use only 0.14mm² (#26 AWG) or larger wire.

5.7.1 Alarm (Relay) Outputs

Terminals provide contacts for extending various alarm or control signals. Each relay output can be wired for NO or NC operation during an alarm or control condition. See Figure 12.




Figure 12—Showing relay connections

Relays can be programmed to energize or de-energize during an alarm condition (see CXC Software manual). When the CXCI reset button is pressed or power is lost, all relays de-energize.

5.7.2 Digital Inputs for CXCI

The digital input channels (factory-installed) are used to monitor various alarm and control signals. All input channels are voltage activated and accept a bipolar (i.e. negative or positive) DC signal directly.

For the CXCI option, only D1 and D2 are available.

5.7.2.1 Connection Method

Typical Argus systems use the “reset with Hot and trigger with Ground” connection. The digital input is wired in such a way that the Hot is wired directly into one of the input terminals; e.g., negative input for -48V systems. The other input terminal is wired to the Ground (common) of the system through a relay (dry contact – usually located on the equipment requiring monitoring). This method (see Figure 13) allows the digital input to receive (or not receive) a Ground signal on an alarm.




Figure 13—Showing digital input connection method

5.7.2.2 Programming the Digital Input

The digital input channels can be programmed for “active high” or “active low.” Active high indicates “alarm on the presence of a ground signal” and active low indicates “alarm on the removal of a ground signal.” See CXC Software manual for detailed instruction on programming.

Voltage Range (VDC)	Voltage Level (VDC) Considered As “0” (Off)	Voltage Level (VDC) Considered As “1” (On)
0—60 (system voltage setting)	0—3	18—60

Table C—Voltage level definitions for digital inputs

5.7.3 Analog Inputs

CAUTION: Ensure the correct polarity is used for all input cable terminations.

The analog input channels are used to monitor various types of electrical signals. Some of the analog channels are reserved for specific signals, while others are designated as general-purpose inputs, which accommodate various types of analog signals.

For the CXCI option, Battery Hot input on the I/O board is factory wired to the battery system voltage terminal for CXCI reference when a battery disconnect device is used. ***It is critical to CXCI operation as it ensures a source of power to the CXCI should the disconnect device open the circuit.***

5.7.3.1 Voltage

Voltage Input #1 (load voltage per CXC software) terminals (V1) on the shelf provide connections to an optional secondary voltage input.

Voltage Input #2 (battery voltage per CXC software) is wired internally (V2) to the converter output voltage of the shelf. This is used as the reference for system alarming (such as high voltage) and control (such as low voltage disconnect).

5.7.3.2 Temperature Sensor

Temperature Probe input channels (T1 and T2) provide connections for temperature sensors. A voltage is supplied to these terminals for sensor measurements.

5.7.3.3 Current

Current Input #1 (discharge or load current per CXC software) terminals (I1) are factory wired to the shunt in this system.

6 System Startup

Visually inspect the installation thoroughly.

After completing the system installation and power system wiring, perform the following startup and test procedure to ensure proper operation:

6.1 Check System Connections

- Ensure power is off, battery breaker is off (if applicable), and all modules are removed from the shelf.
- Triple-check the polarity of all connections.

6.2 Verify Input and Power the Converter Shelf

- Verify input voltage is correct and turn on the corresponding feeder breaker.
- Install one power module. The converter I/P LED should illuminate after a preset start delay.
- Using the CXCI (via web browser), test functionality of various module alarms and controls.
- Install remaining modules.
- In the adjustments menu of the CXCI, set converter voltage.
- Using the CXCI, continue to test the functionality of various module alarms and controls. In addition, perform a load test with the system using a resistive load box as needed.

6.3 Converter Operation and Programming via the CXCI

NOTE: Refer to the current version (1.97 minimum) software manual.

The existing CXC Controller Signals category now includes signals for Converter Load Voltage and Converter Load Current; by default, Average Conv. Output Voltage and Total Conv. Output Current are used respectively.

6.3.1 Load Current in a Rectifier/Converter System

For proper operation of Charge Current Control and Power Save, the system load current must include the current drawn from the rectifiers used to power the converters. Depending on the location of the current shunt in the system, it may be necessary to modify the Load Current equation to add the Total Converter Input Current.

To view the load current of the system load, without the influence of the Converter Input Current, a custom signal can be created; for example, if Load A powers some equipment and Load B is the current drawn by the converters, then the equation for Load A would be: Total Rectifier Output Current - Total Converter Input Current.

6.3.2 Recommendation for Converter Redundancy

During firmware upgrade (programming) of the converter, the converter being programmed will be turned off and not deliver any power. This is largely due to the way in which the converter begins operation after programming.

The power-up sequence for a converter is to start with 0V and 0A for a Start Delay of one through ten seconds. After this period has expired, the converter will ramp up the Output Voltage and Current Limit values to the appropriate settings in about one second. Furthermore, since the converter will be off for at least this amount of time, the present implementation turns off the converter before the programming. The programming time is added to the Start Delay to provide the total amount of time for which the converter will be off or out-of-service.

Therefore, with one redundant converter in a system, the load will still receive power from the other converters while one of them is being programmed.

6.4 CXCI Reset

CAUTION

Before removing a CXCI from a live system, or performing controller maintenance, an external LVD inhibit (or override) is required to avoid a disruption of service.

6.4.1 Soft Reset

The reset button, located on the front panel of the optional CXCI, is for restarting the microprocessor. When pressed momentarily, the unit beeps twice then resets. The front-panel LED's will illuminate temporarily, but will extinguish after the system has finished its 15-second self-test.

6.4.2 CXCI IP Address Reset

To reset the IP address, press and hold the front panel reset button for three seconds. The CXCI unit will beep three times, IP will be reset (to 10.10.10.201) and DHCP will be disabled. The settings will be saved and the unit will then reset.

This will allow local access; e.g., with a laptop and a standard network crossover cable. See current version software manual for details.

6.4.3 CXCI Hard Reset

There is a second reset button located to the right of the front panel on the side of the CXCI. This may be used to restart the microprocessor in the event that the front panel (soft) reset button fails to operate as described above.

CAUTION: Use of hard reset may cause loss of data.

To access the hard reset button, remove the converter module adjacent to the CXCI.

6.4.4 Time Settings

The CXCI, upon startup*, will set the time based on the following:

- Attempt to synchronize with the NTP server (see www.NTP.org).
- Retrieve the last time stamp from the Event Log.
- Retrieve the last time stamp from the Statistics Log.
- Set the time to 2005-01-01 midnight.

* Whenever the unit is reset or power is completely removed from the CXCI.

Canada and USA toll free 24-hour emergency technical support: +1 888 GO ARGUS (462 7487).

7 Maintenance

Although very little maintenance is required with Argus systems, routine checks and adjustments are recommended to ensure optimum system performance. Qualified service personnel should do repairs.

The following table lists a few maintenance procedures for this system. These procedures should be performed at least once a year.



WARNING: HIGH VOLTAGE AND SHOCK HAZARD.

Use extreme care when working inside the shelf while the system is energized. Do not make contact with live components or parts.

Circuit cards, including RAM chips, can be damaged by static electricity. Always wear a grounded wrist strap when handling or installing circuit cards.

Ensure redundant modules or batteries are used to eliminate the threat of service interruptions while performing maintenance on the system's alarms and control settings.

Procedure	Date Completed
Clean ventilation openings	
Inspect all system connections (re-torque as necessary)	
Verify alarm/control settings	
Verify alarm relay operation	

Table D–Sample maintenance log

NOTE: Consult factory for replacement parts.

To order more breakers refer to the options listed in the Specifications Section at the front of this manual. Always replace circuit breakers with the same type and rating.

7.1 Fan Replacement

CAUTION: Use fan assembly with correct connector as supplied by Argus.

1. Shut off the unit and unlatch (rotate 1/4-turn) the front fastener that secures the converter module to the shelf.
2. Slide the module 10 cm (4") out of the shelf and wait two minutes for module capacitors to discharge.
3. Access the fan by removing the screws (top and side) that secure the front panel to the module chassis.
4. Disconnect the fan power lead wires from the module.
5. Note the direction of air flow (into the module front) and remove the fan from the front panel.
6. Install the replacement fan with the correct airflow direction following the preceding steps in reverse order.

NOTE: Use care with fan wire routing so that the lead wires do not become pinched when the front panel is reattached.

7.2 CXCI Replacement (as used with CXDF shelf)

Refer to all safety instructions provided in the documentation package provided with your system.



WARNING: HIGH VOLTAGE AND SHOCK HAZARD.

Use extreme care when working inside the shelf while the system is energized. Do not make contact with live components or parts.



Circuit cards, including RAM chips, can be damaged by static electricity. Always wear a grounded wrist strap when handling or installing circuit cards.

1. Write down the CXCI communication information: dynamic or static IP, IP address, and gateway.
2. Connect user laptop to CXCI per software manual; standard network crossover cable to Ethernet port.
3. A step-by-step connection (wizard) application – provided to establish remote communications with your CXCI – is available via the Argus website (www.argusdcpower.com). The CXC Connection Wizard will save your LAN configuration and restore it back when exiting the application.
4. Save CXCI configuration file (see software manual).
5. Bypass system LVD using LVD Inhibit switch as required and remove signal wires (via DB connectors) from CXCI.

CAUTION: If the LVD is not bypassed, the DC loads will be shut down when the wiring to the controller is removed.


6. Ensure converter is in the right-most position.
7. Remove converter in the left-most position in order to access the side of the CXCI where the mounting screws are located.
8. Continue with the steps illustrated below:

Remove two (2) side mounting screws from the baffle to release the CXCI front panel



Gently remove the LCD to access the front mounting screw

Remove front mounting screw to release the CXCI assembly



Remove the CXCI by disengaging the module from the rear connector (inside the shelf)

Use the baffle to grip the assembly and slide along the shelf bottom

Figure 14—Showing CXCI module removal (replacement)

9. Replace the CXCI following the illustrations above in reverse order.
CAUTION – Use minimal pressure to re-install the LCD.
10. Ensure LCD is straight and aligned parallel to the front panel window when reattaching the CXCI front panel. Continue to step 11 to complete procedure.
11. Review steps 1 through 3 with respect to new installation and upload the saved CXCI configuration file to the new controller.
12. Use a meter to verify the bus voltage and current shunt. Recalibrate as required due to differences in the new CXCI.
13. Replace converters and signal wires. Return LVD Inhibit switch to normal.

8 Argus Conventions

8.1 Numbering System

Argus Technologies uses an eight-digit drawing number system, which is broken into three blocks. The first three digits describe the category of the product; e.g., converter or fuse panel. The next three digits indicate the sequence in which the product number was allocated in a particular category. The last two digits indicate the type of drawing, for example:


"-05"	Schematic
"-06"	Outline Drawing
"-08"	Customer Connections
"-20"	Main Assembly

Argus uses an eight-digit part numbering system for all components and sub assemblies. Each part is covered by its own unique number. Due to the quantity, categories will not be listed within this manual.


8.2 Acronyms and Definitions

AC	Alternating current
ANSI	American National Standards Institute
AWG	American Wire Gauge
BTU	British thermal unit
CAN	Controller area network
CEC	Canadian Electrical Code
CMA	Circular mil area
CSA	Canadian Standards Association
CX	Cordex™ series; e.g., CXC for <u>C</u> ordex <u>S</u> ystem <u>C</u> ontroller
DC	Direct current
DCP	Distribution Center Plug-In
DHCP	Dynamic Host Configuration Protocol
EMC	Electromagnetic compatibility
EMI	Electromagnetic interference
ESD	<u>E</u> lectrostatic <u>D</u> ischarge
FCC	Federal Communications Commission (for the USA)
IEC	International Electrotechnical Commission
IEEE	Institute of Electrical and Electronics Engineers
IP	Internet Protocol
LED	Light emitting diode
LVD	Low voltage disconnect
MIL	One thousandth of an inch; used in expressing wire cross sectional area
MTBF	Mean time between failures
NC	Normally closed
NEC	National Electrical Code (for the USA)
NO	Normally open
OSHA	Occupational Safety & Health Administration
OVP	Over voltage protection
RAM	Random access memory
RU	Rack unit (1.75")
TCP/IP	Transmission Control Protocol / Internet Protocol
UL	Underwriters Laboratories


REVISIONS				
LTR	DESCRIPTION	DWN	DATE	APPD




FRONT VIEW



SIDE VIEW



CXPS 24-1.8-i
BASE 19"/23" SYSTEM CONFIGURATION 053-996-20-000 SHOWN
(UNIVERSAL 19/23" RACK MOUNT)



SIDE VIEW
WITH REAR KYDEX COVERS INSTALLED

ARGUS®

THESE DESIGNS AND SPECIFICATIONS ARE THE PROPERTY OF ARGUS TECHNOLOGIES AND SHALL NOT BE COPIED OR USED FOR MANUFACTURING WITHOUT ITS WRITTEN CONSENT.

UNITS: mm [in]	
X [X.X]	±1 [±0.040]
XX [XX.X]	±0.5 [±0.020]
XXX [XXX.X]	±0.05 [±0.002]
ANGULAR:	±0.5°



SCALE: NTS


TITLE: OUTLINE, CXPS 24-48-i
CONVERTER SYSTEM

NAME	DATE	ISSUE	SHEET
DESIGN BK	2009/02	DATE	1 OF 1
DRAWN SDW	2009/02	DATE	
CHECKED		DATE	
APPROVED		DATE	

SIZE	TYPE	DWG NO.	REV
B	D2	053-996-06	A

© 2009 ARGUS TECHNOLOGIES

REVISIONS			
LTR	DESCRIPTION	DATE	APPD
A	Renamed V1	08/12	






NOTES:

- 1) FOR CONTINUOUS OPERATION, IT IS RECOMMENDED THAT SHUNTS ARE NOT RUN AT MORE THAN 80% THE RATED CURRENT UNDER NORMAL CONDITIONS.
- 2) DASHED LINES DENOTE CUSTOMER WIRING.
- 3) ALL WIRES ARE #18AWG EXCEPT AS NOTED.
- 4) NUMBERS IN BUBBLES REFER TO ITEM NUMBERS ON BILL OF MATERIALS.
- 5) "□" REFERS TO WIRE TAG NUMBERS ON WIRES.
- 6) D1 & V1 ARE INTERNALLY WIRED (REFER TO 020-705 Sheet 3 of 8 SCHEMATIC)

LTR	DESCRIPTION	QTY
	FINISHED HOLE LEGEND	
ARGUS®		
THESE DESIGNS AND SPECIFICATIONS ARE THE PROPERTY OF ARGUS TECHNOLOGIES AND SHALL NOT BE COPIED OR USED FOR MANUFACTURING WITHOUT ITS WRITTEN CONSENT.		
DESIGN	DD 08/12/02	MATERIAL
DRAWN	DD 08/12/02	
CHECKED	R.W. 08/12/03	
APPROVED	R.W. 08/12/03	FINISH
TOLERANCES (UNLESS OTHERWISE NOTED)		
SCALE		N/A
TITLE		
CXPS 24 to 48VDC Converter System		
ISSUE		SHEET 1 OF 1
DATE		REV
SIZE	TYPE DWG NO.	
B A2	053-996-05	A

REVISIONS				
LTR	DESCRIPTION	DWN	DATE	APPD



ARGUS®

THESE DESIGNS AND SPECIFICATIONS ARE THE PROPERTY OF ARGUS TECHNOLOGIES AND SHALL NOT BE COPIED OR USED FOR MANUFACTURING WITHOUT ITS WRITTEN CONSENT.

UNITS: mm [in]	
X [X.X]	±1
X.X [X.XX]	±0.5
X.XX [X.XXX]	±0.05
ANGULAR:	±0.5°




SCALE: NTS

TITLE: CONNECTION,
CXPS 24-48-i CONVERTER
SYSTEM


NAME	DATE	ISSUE	SHEET	OF
DESIGN BK	2009/02	DATE	1	3
DRAWN SDW	2009/02	DATE		
CHECKED		DATE		
APPROVED		DATE		

SIZE	TYPE	DWG NO.	REV
B	D2	053-996-08	A

© 2009 ARGUS TECHNOLOGIES





LVD OVERRIDE / DISTRIBUTION ALARM PCB




CXCI INTERFACE PCB

020-702-20 CONNECTION DETAILS

<h1>ARGUS®</h1> <p>THESE DESIGNS AND SPECIFICATIONS ARE THE PROPERTY OF ARGUS TECHNOLOGIES AND SHALL NOT BE COPIED OR USED FOR MANUFACTURING WITHOUT ITS WRITTEN CONSENT.</p>															
<p>UNITS: mm [in]</p> <table><tr><td>X [X.X]</td><td>±1</td><td>[±0.040]</td></tr><tr><td>XX [XX.X]</td><td>±0.5</td><td>[±0.020]</td></tr><tr><td>XXX [XXX.X]</td><td>±0.05</td><td>[±0.002]</td></tr><tr><td>ANGULAR:</td><td>±0.5°</td><td></td></tr></table>		X [X.X]	±1	[±0.040]	XX [XX.X]	±0.5	[±0.020]	XXX [XXX.X]	±0.05	[±0.002]	ANGULAR:	±0.5°		 <p>SCALE: NTS</p>	
X [X.X]	±1	[±0.040]													
XX [XX.X]	±0.5	[±0.020]													
XXX [XXX.X]	±0.05	[±0.002]													
ANGULAR:	±0.5°														
<p>TITLE: CONNECTION, CXPS 24-48-i CONVERTER SYSTEM</p>															
<p>ISSUE DATE:</p>		<p>SHEET 2 of 3</p>													
SIZE B	TYPE D2	DWG NO. 053-996-08	REV A												
© 2009 ARGUS TECHNOLOGIES															



REAR VIEW




RIGHT SIDE VIEW

**030-905-20 CONNECTION
DETAILS**

ARGUS®

THESE DESIGNS AND SPECIFICATIONS ARE THE PROPERTY OF ARGUS TECHNOLOGIES AND SHALL NOT BE COPIED OR USED FOR MANUFACTURING WITHOUT ITS WRITTEN CONSENT.

UNITS: mm [in]	
X [X.X]	±1 [±0.040]
X.X [X.XX]	±0.5 [±0.020]
X.XX [X.XXX]	±0.05 [±0.002]
ANGULAR:	±0.5°



TITLE: CONNECTION,
CXPS 24-48-i CONVERTER
SYSTEM

ISSUE		SHEET	3 OF 3
DATE			
SIZE	B	TYPE	D2
DWG NO.	053-996-08	REV	A

© 2008 ARGUS TECHNOLOGIES

WARRANTY AND SERVICE INFORMATION

Technical Support

Technical support staff are available for answering general questions related to installation, operation and maintenance of Argus products. In Canada and the USA, call Argus toll free at +1-888-GO-ARGUS (+1-888-462-7487) 7:30 am to 5:00 pm Pacific Standard Time.

For emergencies, call +1-888-GO-ARGUS (+1-888-462-7487) 24 hours a day, seven days a week. Customers outside Canada and the USA, call +1-604-436-5547 for technical support.

Factory Repair and Servicing

All service, beyond initial adjustments, should be carried out by qualified factory service personnel. For these procedures, please contact Argus Technologies at the locations listed in the Service Centers document.

Warranty Policy

Argus Technologies Ltd. warrants all equipment manufactured by it to be free from defects in parts and labor, excluding third party OEM materials (example: air conditioners, batteries), for a period of two years from the date of shipment from the factory. For third party products the OEM's warranty shall apply. The liability of Argus applies solely to repairing, replacing or issuing credit (at Argus' sole discretion) for any equipment manufactured by it and returned by the customer during the warranty period. The terms of the warranty are Ex Works (EXW) from Argus' factory service location.

Argus reserves the right to void the warranty if:

- (1) identification marks or serial numbers are removed or altered in any way,
- (2) invoice is unpaid, or
- (3) defect is the result of misuse, neglect, improper installation, environmental conditions, non-authorized repair, alteration or accident.

Argus shall not be liable to the customer or other parties for any loss of profits, loss of use, costs for removal or installation of defective equipment, damages or consequential damages based upon equipment failure during or after the warranty period. There shall be no other obligations either expressed or implied. Argus will not honor warranties for batteries and other third party products without prior written Argus authorization.

Customer is responsible for all shipping and handling charges (COD and freight collect will not be accepted without prior approval from Argus Technologies).

Payment terms (North America) are net 30 days subject to prior credit approval. All other orders require payment before shipping.

Payment terms (International) are subject to prior approval and are typically through Tele-Transfer.

Return Material Policy

Our return policy is designed to ensure prompt, efficient and high quality factory service. A service request order (SRO) number must be obtained before products can be accepted for servicing by the Argus factory. For returns to an authorized service center (refer to the Service Centers document), please consult the individual service center for specific return policies and instructions.

To obtain an SRO number for a factory return, customers must call the appropriate location with the product serial and model number, as well as a brief description of the problem, shipment instructions and billing details.

The original packing container should be used whenever possible. The box should be completely enclosed and constructed of wood or double-wall, corrugated cardboard. At least 3" of foam or shock absorbing packing material must surround the unit. Both the shipping documents and the outside of the box must have the SRO # clearly marked and the product shipped prepaid to the Argus factory service center. Argus will endeavor to repair products within five working days of receipt. Repairs to the returned product are warranted for a period of six months. A service charge may be applied if no fault is found in the returned product. Argus will not accept products without an SRO number.

Service Centers

Factory Service Centers

Canada and International

Argus Technologies Ltd.
ATTN: RMA Returns
7033 Antrim Avenue
Burnaby, BC, V5J 4M5 Canada
Tel: +1 604 436 5900
Fax: +1 604 436 1233
Email: returns@argusdcpower.com

USA

Argus Technologies Inc.
ATTN: RMA Returns
3116 Mercer Avenue
Bellingham, WA, 98225 USA
Tel: +1-360 756 4904
Fax: +1-360 647 0498
Email: returns-usa@argusdcpower.com

Asia-Pacific

PCM Electronics (Dong Guan) Co., Ltd.
Hongli Industrial Area, Miaobian,
Liaobu Town, Dongguan City,
Guangdong Province, 523400 China
Tel: +86 755 8895 3310
Fax: +86 755 8895 3307

Authorized Service Center

Argentina

Argus Technologies de Argentina
Belen 315, Capital Federal, Buenos
Aires,
14071 Argentina
Tel: +54 (11) 4672 4821
Fax: +54 (11) 4504 4698
Cell: +54 9 (11) 4993 9996
Email: lkleiman@argus.ca

Asia

Argus Technologies Asia Pte Ltd
Blk 6 Tagore Lane #160
Singapore 787570
Tel: +65 6458 8900
Fax: +65 6458 2122

Australia

CPS National
8/376 Newbridge Rd
Moorebank, NSW, 2170 Australia
Tel: +61 02 9822 8977
Fax: +61 02 9822 8077

Australia/New Zealand

Alpha Power Systems Pty Ltd.
Unit 3, 30 Heathcote Road
Moorebank, NSW, 2170 Australia
Tel: +61 02 9602 8331
Fax: +61 02 9602 9180

Century Yuasa

37 - 65 Colbalt Street
Carole Park QLD 4300
Australian Sales & Service
Tel: +61 07 3361 6587
Fax: +61 07 3361 6705
New Zealand Sales & Service
Tel: +64 9 978 6689
Fax: +64 9 978 6677

Brazil

Argus Brasil Serviços e Comércio Ltda
Rua: Constituição, 145/147 - Santos
São Paulo - Brasil 11015-471
Tel: +55 (13) 3234 2469
Fax: +55 (13) 3234 2469
Cell: +55 (13) 7806 1438
Email: argusbrasil@bignet.com.br

Canada

Compower Systems Inc.
118 Tiffield Road
Toronto, ON, M1V 5N2 Canada
Tel: +1 416 293 3088
Fax: +1 416 293 0671

Europe

Alpha Technologies Europe Ltd.
Cartel Business Estate
Edinburgh Way
Harlow, Essex, CM20 2DU UK
Tel: +44 1279 422110
Fax: +44 1279 423355

Mexico & Central America

Technologies Argus First De Mexico
SA de CV
Anatole France No. 17
Col. Polanco
Mexico City, 11560 Mexico
Tel: +52 55 5280 6990
Fax: +52 55 5280 6585

Romania

Alphapower SRL
Str. Paul Constantinescu nr.5
Timisoara, Romania
Tel: +40 21 569 1214
Cell: +40 31 816 1491

South America

Argus Technologies Argentina
Santo Tome 2573, Capital Federal
Buenos Aires, 1416 Argentina
Tel: +54 11 4504 4698
Cell: +54 9 11 4993 9996
E-pager: 541149939996@nextel.net.ar

Turkey

IPC Enerji Elk San ve TIC AS
Inonu cad. Kanarya sok. No:20
Yenisahra - Kadikoy
Istanbul, Turkey
Tel: +90 216 317 41 42
Fax: +90 216 472 90 66